


Arxus Foot Measurement

| SIZE | FOOT LENGTH | FOOT WIDENESS |
|------|-------------|---------------|
| | MM | MM |
| 36 | 222 | 80 |
| 37 | 232 | 83 |
| 38 | 239 | 85 |
| 39 | 246 | 88 |
| 40 | 256 | 91 |
| 41 | 264 | 94 |
| 42 | 270 | 96 |
| 43 | 280 | 99 |
| 44 | 288 | 102 |
| 45 | 299 | 105 |
| 46 | 309 | 107 |
| 47 | 314 | 110 |
| 48 | 324 | 113 |



Press the inside of the foot against a wall.
Hold a ruler or similar under the foot and measure the width of the foot.
Hold a 90 degree angle to the wall and mark the big toe with a dot.
Make a similar mark behind the heel.
Add 8 - 12 mm to the measured foot length to achieve a needed open space in front of the big toe.